



City of
Burnaby

City of Burnaby Fire Department
fire@burnaby.ca

New Construction Inspection Procedures

NEW CONSTRUCTION/BUILDING FINAL FOR WET/DRY SPRINKLER & COMMERCIAL COOKING

Wet/Dry Sprinkler Trip Test Inspection

- In order for a witnessed trip test by a Burnaby Fire Prevention Officer
- Fire Alarm System shall be verified with no deficiencies
- Sprinkler engineer shall conduct a prior test and record times
- Recorded times shall be given to FPO Inspector before he witnesses test
- A schedule C-B must be provided to FPO Inspector
- It is the owners responsibility to set-up a final test by co-ordinating the Engineer/Building Dept./Fire Inspector

Commercial Cooking System Trip Test Inspections

1. In order for a witnessed trip test by a Burnaby Fire Prevention Officer
 - a) The Engineer shall conduct his own trip test
 - b) When system passes a copy of schedule C-B is to be provided to FPO inspector
2. It is the owners' responsibility to set-up a final trip test by co-ordinating the Engineer/Building Dept/Fire Inspector.

Any questions contact Burnaby Fire Prevention Officer @ 604-294-7195